

INTRODUCTION

Warning: Always be sure you are grounded whenever handling any of the circuit or logic boards.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [T5 Torx Screwdriver](#) (1)
-

Step 1 — LCD Screen



- Remove the back panel by sliding it up.

Step 2



- Remove the battery.

Step 3



- Remove the 4 torx-head screws in the corners of the phone using the T5 Torx Screwdriver.

Step 4



- Use the plastic opening tool to remove the front panel from the phone.
- Be sure to unplug the front button cable from the inside of the phone.

Step 5



- Unscrew the 2 torx-head screws at the base of the LCD screen using the T5 Torx Screwdriver.

Step 6



- Separate the motherboard from the black plastic casing.
- Unplug the black and red wire from the motherboard.
- Unplug the black and red wire from the black plastic casing.

Step 7



- Lift the black lever next to the orange ribbon cable to remove the LCD screen.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 03:36:45 AM.